CABINET PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2314274	Service & Wiring Sheet
	2320053	Energy Label
	2314472	Use & Care Guide
Following May Be Purchased		
DO−IT−YOURSELF REPAIR MANUALS		
	677969	Do−It−Yourself Manual Ref./Fzr.
2	2189410	Hinge (Top)
3	2166108	Roller, Front (2)
4		Cabinet (Not a Serviceable Part)
5	489385	Clamp, Tube (Water Supply Line)
6	8281265	Screw
10	2179826	Rivet
11	3400504	Screw
12	549193	Clamp, Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
20	2254473	Hinge Butt
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2200924	Biscuit
35		Corner Filler (2)
	2201014	White
	2200926	Biscuit
36		Grille (Includes Illus. 39)
	2254313	White
	2254316	Biscuit
37	489341	Washer
38	487576	Washer
39	2189356	Clip, Grille (2)
40		Cover, Hinge
	2213360	White
	2213364	Biscuit
41		Rail, Center (Not Serviced)
44	2202884	Cover, Unit

DOOR PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00

(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Illus. 9 & 22)
	2183920	White
	2205284	Biscuit
2		Handle, Trim
	2193353W	White
	2193353T	Biscuit
5		Handle, Refrigerator
	2213112W	White
	2213112T	Biscuit
6	489357	Screw
7	8281206	Screw
8	8281146	Screw
9	2202875	Door Gasket, Magnetic
13	2262218	Nameplate
16	2195378	Trim, Door Shelf
19		Freezer Door (Includes Illus. 22, & 23)
	2182489	White
	2204686	Biscuit
20		Hole Plug, Handle
	2189000	White
	2200936	Biscuit
21	2188236	Shelf, Flip−Up
22	2183003	Thimble
23	2214967	Door Gasket, Magnetic
25	2204812	Bin, Door Shelf
26	2189202	Bracket, Door Stop (2)
27	488921	Screw
28		Hole Plug
	2212648	White
	2212649	Biscuit
29	2156007	Plug, Trim
30	2156006	Plug, Trim
31	2218118	Compartment Door
33		Handle, Freezer
	2213111W	White
	2213111T	Biscuit
37	2195947	Trim, Door (2)
41	2195916	Endcap (4)
42	2195948	Trim, Door

LINER PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00

(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2197380	Grommet (2)
3	2254360	Gasket, Evaporator Cover (2)
4	2304099	Control, Adaptive Defrost
5	2212485	Thermostat Tube Barrier
6	941839	Hole Plug
7	2310057	Wire Assembly, Control Box
8	2162085	Socket, Light
9	2179858	Damper, Air
10	2219689	Fan Motor
11	2163777	Fan Blade
12	2212982	Control Box
13	2200859	Thermostat Assy. (Includes Illus. 5 & 18)
14	489478	Screw
15	488208	Screw
16	2254263	Cover, Evaporator
17	527949	Light Bulb (2)
18	2200831	Weight, Thermal
19	1118894	Switch, Rocker Arm
20	2179859	Post, Damper
21	2176281	Cover, Air Diffuser
22	2200863	Knob, Thermostat
23	2254354	Air Tower
24	2189452	Air Diffuser, Bottom
26	2212439	Air Separator Assembly
27	2205003	Cover, Hole
28	8534009	Screw
29	2254453	Bracket, Fan Motor
31	2204639	Shield, Heat
32	487996	Cap
33	2254454	Bracket Evap. Fan, Rear
34	2302536	Knob, Damper
35	2163810	Bracket, Damper Knob
36	2205079	Seal, Rear Thermostat
37	2171931	Valve−Tube, Body
38	2314158	Defrost Bi−Metal
39	2310039	Wire Assembly, Freezer Compartment (Includes Illus. 38)
40	940014	Hole Plug, Control Box

UNIT PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00

(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00

(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2225596	Plate, Unit Mounting
2	2169104	Insulation, Sound Dampening
3	2214960	Condenser
4	2314157	Heater, Defrost
5	2254249	Evaporator Assy.
7	2254295	Drain Pan
8	8533859	Screw
9	2176301	Bracket, Heater
10	2300638	Extension, Air Baffle
11	2255113	Strap, Compressor
12	4387731	Cover (Service Only)
13	4390624	Overload (Service Only)
14		Grommet (4)
	1100826	Production
	4387758	Service
15	2225929	Start−Device Combination (Start Relay and Overload for Production Compressor Only)
16	2201185	Support Block
17	2150304	Roller (2)
18	2221797	Rivet
19	2182338	Clip, Heater
20	489373	Screw
21	3400518	Screw
23	2183454	Relay (Service Only)
28	2218968	Compressor (Includes Illus. 12,13,14, 23,29,32 & 33)
29		Drier
	2319825	Production
	4387019	Service
30	2155774	Clamp
32		Capacitor
	2169373	Production
	1118576	Service
33	4387765	Wire Assembly (Service Only)
39	2302249	Air Baffle
40	2188874	Motor, Condenser
42	2187382	Wire Assembly Unit
43	2225834	Fan Blade
46	2205384	Tube, Discharge
47	2225237	Tube, Suction
48	2154109	Tube, Process
56	488500	Screw
58	2300635	Tray, Evaporator

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE

4.00 Ozs.
(R134A)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00

(White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2300520	Shelf, Ladder Center
3	2163762	Cup, Shelf Mtg.
4	3400065	Screw
5	489478	Screw
9	2210524	Crisper Cover
10	2214911	Shelf, Cantilever
11	2210573	Insert, Crisper Cover
12	2214909	Pan, Shelf Cantilever
13	2214913	Glass, Shelf
15	2314478	Crisper Support
17	2184667	Shelf, Freezer
20	2218132K	Pan, Meat
21	2214892	Track, Pan Slide (2)
24	2218124	Crisper Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: ET1FTEXSQ00, ET1FTEXST00
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Miscellaneous

978941	Insulation, Fiberglass (63−1/2" x 35−1/2" x 2−5/8")
212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4" x 108")
876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
505587	Sealer, Mastic (1 Qt.)
511873	Touch−Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
606755	Bag, Insulation (36−5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
799832	Kit, Porcelain Repair (White)
503695	Cork Sealer (1/4 Pound)

Customer Touch−Up Material

*350942	Primer, White (12 Oz. Spray Can)
*350939	Enamel, Black (12 Oz. Spray Can)
*350930	Enamel, White (12 Oz. Spray Can)
*4392901	Enamel, Biscuit (12 Oz. Spray Can)
72017	Brush Touch−Up Kit (White)
72032	Brush Touch−Up Kit (Black)
4392899	Brush Touch−Up Kit (Biscuit)

Refinishing Material

799340	Enamel, Black (1 Qt. Uncut)
799344	Enamel, White (1 Qt. Uncut)
4392900	Enamel, Biscuit (1 Qt. Uncut)
833938	Kit, Terminal Connector

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

ICE MAKER FIELD INSTALLABLE

2155469	ECKMF94

TORX SCREW WRENCH

1117510	Torx Key